

INSTALL MOUNTING PLATE

TIGHTEN MOUNTING PLATE

SNAP ON HINGE ARM

RELEASE HINGE ARM

INSERT HINGE BOSS INTO DOOR

TIGHTEN HINGE BOSS INTO DOOR

+/- 2mm

+/- 2mm

+3mm -2mm

+/- 2mm

+/- 2mm

+3mm -2mm